

MNT Research GmbH Fehlerstr. 8, 12161 Berlin WEEE: DE 33315564 https://mntre.com

Specifications

Dear MNT Customer,

Thank you for purchasing MNT x Kolibri HALO-90, our fully open hardware electronic earrings. We hope you'll enjoy your new jewelry.



Quickstart

1. Remove the small film between battery and battery holder.

2. Turn the earrings on by pressing the small button for 1-2 seconds. The LEDs will light up.



3. To circle through the 3 different modes, press the same button. Hold the button for 1-2 seconds to turn off the earrings.

4. If the battery runs out, replace it with a new one (CR2032 coin cell).

- 90 fully controllable LED lights
- 3 modes: Dynamic, Halo, Sparkle
- Powered by a CR2032 coin cell •
- Runtime: approx. 13 hours
- Dimensions: 24 mm x 26 mm x 6.36 mm
- Weight: 5.2 g

Contents

- MNT x Kolibri HALO-90 Earrings
- Optional Earring Case
- Quickstart and Safety Sheet

Software and Sources

Find more information on documentation: https://github.com/openKolibri/halo-90

Warranty

MNT Research covers the warranty to the extent required by law for the unmodified product and following the safety instructions. Warranty does not cover any modifications made to the product.

Safety Instructions

Keep away from fire. Keep out of reach of children. When storing the earrings for a longer period, remove the batteries.

(F

The product complies with the requirements of the **European Directives and DIN standards:**

EMC Directive 2014/30/EU (EN 55032:2015/A11:2020, EN 55035:2017/A11:2020) Low Voltage Directive 2014/35/EU (EN 62368-1:2014) RoHS Directive 2011/65/EU (EN 63000:2018) Batteries Regulation (EU) 2023/1542

Get updates and source code at: mntre.com

Need help? Join community.mnt.re or write to support@mntre.com

Join our IRC channel #mnt-reform