

MNT Research GmbH Fehlerstr. 8, 12161 Berlin WEEE: DE 33315564 https://mntre.com


MNT ZZ9000 R-4 Quickstart Manual

Dear MNT Customer,

Thank you for purchasing the MNT ZZ9000 Graphics Coprocessor Card (with Ethernet and USB Storage) for Commodore Amiga computers. This product was made possible by your support.

Package Contents

- MNT ZZ9000 Zorro card (1) with mounting bracket and 128MB MicroSD card (4) containing ZZ9000OS
- MNT ZZ9000CX ECS/AGA Video Slot adapter (2)
- Video Slot ribbon cable for connecting both cards (3)
- This manual



Warranty

MNT Research covers the warranty to the extent required by law for the unmodified product. ZZ9000 is based on a reconfigurable Xilinx ZYNQ Z-7020 FPGA that can be updated by the user and reprogrammed to enable new functionality. Warranty does not cover user supplied firmware or any modifications made to the card, nor does it cover any damage by inserting it into a computer or other user supplied device. Use at your own risk!

Conformity

MNT ZZ9000 may only be operated in a shielding steel enclosure. MNT Research assures that the included product complies with the requirements of the following European Directives and DIN standards:





EMC Directive 2014/30/EU (EN 55032:2015/A11:2020, EN 55035:2017/A11:2020) Low Voltage Directive 2014/35/EU (EN 62368-1:2014) RoHS Directive 2011/65/EU (EN 63000:2018)

Get updates and source code at: https://mntre.com/zz9000

Need help? Write to zz9000@mntre.com

Join our IRC channel #mnt-amiga on irc.libera.chat

Hardware Installation

- **1. Connect the Video Slot ribbon cable** by inserting one end into the 34 pin socket of ZZ9000 and the other end into the 34 pin socket of ZZ9000CX.
- 2. Insert ZZ9000 into any of the Zorro slots of your Amiga 2000/3000/4000.
- **3. Insert ZZ9000CX** into the Video Slot of your Amiga. In Amiga 2000, the Video Slot is on the right side of the power supply. In Amiga 3000, the Video Slot is located next to the top Zorro slot on the daughterboard. In Amiga 4000, the Video Slot is next to the bottom Zorro slot on the daughterboard.

There are two distinct firmware (BOOT.bin) files for Zorro II and Zorro III support. ZZ9000 ships with the firmware that you selected when ordering. To change it, just download a new firmware file and copy it to the MicroSD card inserted in ZZ9000.

Software Installation

- 1. Install the RTG (ReTargetable Graphics) system. There are two options:
- Picasso96 on Aminet: http://aminet.net/package/driver/video/Picasso96
- P96 3.x by Individual Computers (recommended). To purchase a license, first register an account in their shop. More information: http://wiki.icomp.de/wiki/P96

When installing Picasso96/P96, select only the **Altais** card. The ZZ9000 Installer will copy it to create its own Devs:Monitors/ZZ9000 driver file.

- **2. ZZ9000** implements a SANA-II compatible network card that you can use to go online with TCP/IP stacks such as Miami or Roadshow. Make sure you have such a TCP/IP stack installed before installing the network driver.
- **3. Double click "Install ZZ9000"** from the ZZ9000 Install package available from our website or on floppy disk from our online shop. The ZZ9000 Installer will guide you through all steps necessary to set up the graphics, network and AHI/MHI (requires separate MNT ZZ9000AX module) functions.
- **4. After rebooting**, you will be able to select high resolution 8/16/32 bit screen modes using ZZ9000's display engine. Native Amiga chipset screen modes will be automatically scan-doubled and flicker-fixed via ZZ9000CX.
- 5. You can use a USB stick to exchange files between your Amiga and other computers via zzusb.device that is automatically loaded as part of the firmware. The USB stick needs to be formatted with the Amiga FFS filesystem and RDB partition table for this to work. The first partition should be below 4GB in size. You can use HDInstTools (with zzusb.device set up as the device in its Icon Information) to create the partition and format it with Amiga tools, or use an emulator such as WinUAE. On Linux, you can mount Amiga partitions from the stick by passing the option -t affs to the regular mount command.

Running ARM Software

ZZ9000 has two 32-bit ARM Cortex-A9 processor cores that run at 666 MHz. The system has access to 1 GB of DDR3 memory in total. A part of this memory is directly shared with the Amiga's chipset and 68000 familiy processor via the Zorro Bus. The Amiga RTG screens also occupy the same memory space, so both ARM and Amiga can draw pixels into graphics memory or read from it. Normally, a mini operating system called ZZ9000OS is running on ARM Core 1, and ARM Core 2 is idle. ZZ9000OS has the following functions:

- Polls the Zorro bus in the FPGA fabric for events (writes, reads, or Amiga reset)
- Receives and transmits Ethernet packages
- Controls the DVI transmitter
- Controls the USB port
- Executes accelerated RTG drawing functions like fills, scrolling, text, patterns

You can run custom code on ARM Core 2 by loading it into a place in shared memory and asking ZZ9000OS to jump into the code. On the ZZ9000 website (https://mntre.com/zz9000) you can download example progams and a simple SDK for writing your own ARMv7 applications, as well as the sources for ZZ9000OS.


Updating FPGA Firmware and ZZ90000S

Development of ZZ9000 has taken almost two years, and it was our priority to get the hardware into your hands as soon as possible while delivering a good feature set to begin with. But ZZ9000 is highly extensible and open source. In addition to us delivering new features for the card, we believe that the hackers and makers among you will come up with fantastic new software and ideas to run on ZZ9000.

The ZYNQ on ZZ9000 boots from the inserted MicroSD card. This card needs to be MBR partitioned and FAT32 formatted. The system looks for a file called BOOT.bin which contains the ZYNQ FSBL (first stage boot loader) that in turn loads the FPGA image and ZZ9000OS (in ELF format). To update the card, you simply have to replace the BOOT.bin file with a new one.

ARM Address	Amiga Address*	Area
\$0010_0000	N/A	DDR3 Start, ZZ9000OS Code
N/A	\$0000_0000	ZZ9000 ARM Registers
N/A	\$0000_1000	ZZ9000 FPGA Registers
N/A	\$0000_2000	Ethernet and USB Buffers / Scratch Space
\$0020_0000	\$0001_0000	Framebuffer Memory Start
\$005F_0000	\$0040_0000	Zorro 2 Accessible Space End (4 MB)
\$0300_0000	\$02E1_0000**	ARM Application and General Purpose Shared Space Start
\$101F_0000	\$1000_0000	Zorro 3 Accessible Space End (256 MB)
\$4010_0000	N/A	DDR3 End (1 GB)

^{*}Relative to card address



Please note that during ethernet driver installation, you can choose any MAC

address you like.

shown here. Introduced in R-2.

^{**}Currently unreachable on Zorro 2 machines